



# Wasatch -PROFILE READ ME

**Important:** Please make sure the following criteria are met for optima color fastness. Room humidity should be kept above 30% and below 60%. Room Temperature should be kept above 50F and below 75F. Low humidity and other items such as rugs or carpets around the printer can cause Static electricity which can show as anomalies on your prints. High humidity and high temperatures can cause curling of media or head strikes from the printer.

## Contents of ZIP file:

1. Readme File
2. Wasatch media Folder

## Intsall Instructions

### RIP - Wasatch 6.1

**Step 1** - Before opening your RIP program place the Uzipped folders into your configuration folder, which can be found at: **x:\wwrip6\configurations\“your printer”**  
*x= “the drive you installed Wasatch”*

**Step 2** - Once the folders have been placed they are immediately accessible for use.

**Step 3** - In the main screen of Wasatch SoftRIP go to the **“Print”** menu then choose **“Setup”**. You will be taken to another screen where you can choose your media.

**Step 4** - Once you have enetered the **“Setup”** screen, please go to the Imaging Configuration part and scroll until you find the desired Creative Banner Media.

**Step 5** - Make sure to check your **“Paper Width”** and set this to width of your media.

**Step 6** - Congratulations! You are now ready to print using this media.

## Handling of Media Recommendations

1. Always make sure you wear gloves as your hand carry oils that release themselves on to the media and may cause the solvent ink not to adhere properly.
2. If you printer is on carpet or a room that is very low in terms of humidity, it is recommended to have an anti-static string, grounding bars or anti-static device to reduce or eliminate static build-up on the material prior to printing.

Please enjoy this and other medias as provided by General Formulations. Thank you.